I'm not a bot

Black and decker coffee maker instructions

1 2 -C U P * P R OG R A M MA BL E COFF E E M AK E R C A F ET E RA P R O GR A M A B L E D E 1 2 TA Z AS * C A F ET I È RE P RO G R A MM A B L E D E 1 2 TASS E S * u s e a n d c a re m a n ua l m an u a l d e u so y c ui d a do g u i d e d ' u t il is atio n et d'e nt ret ie n C M 1 1 1 0 S e rie s S e r i e C M 1 11 0 S é r i e C M 1 11 0 Should you have any questions or concerns about your new product, please call our Customer Service Line at 1-800-465-6070 (U.S. and Canada). Please do not return to the store. ¡Deseamos que disfrute de una experiencia de 5 estrellas! Si usted tiene alguna inquietud o pregunta con su producto, por favor llame a nuestra línea de servicio al cliente al 1-800-465-6070 (EE.UU/Canadá) 01-800-714-2503 (México). Nous voulons que vous ayez une expérience 5 étoiles! Si vous avez des questions ou des préoccupations à propos de votre nouveau produit, veuillez communiquer avec notre Service à la clientèle au 1 800 465-6070 (Ëtats-Unis et Canada). *One cup equals approximately 5 oz. (varies by brewing technique) *Una taza equivale a aproximadamente 5 onzas. (varía de acuerdo al método de preparación utilizado) *Une tasse équivaut à environ 115 g (5 oz; varie selon la technique de brassage) We want you to have a 5-star experience! No lo devuelva a la tienda. Veuillez ne pas rapporter le produit au magasin. 1 PLEASE READ AND SAVE THIS USE AND CARE BOOK.POR FAVOR LEA ESTE INSTRUCTIVO ANTES DE USAR EL PRODUCTO.VEUILLEZ LIRE ET CONSERVER CE GUIDE D'ENTRETIEN ET D'UTILISATION. IMPORTANT / IMPORTANTE / IMPORTANT WASH CARAFE BEFORE FIRST USE! LAVE LA JARRA ANTES DEL PRIMER USO LAVER LA CARAFE AVANT LA PREMIÈRE UTILISATION! Model/Modelo/Modèle TCM830 Accessories/Parts (USA/Canada) Accesorios/Partes (EE.UU/Canadá) Accessoires/Pièces (É.-U./Canada) 1-800-738-0245 USA/Canada 1-800-231-9786 Mexico... How to UseThis appliance is intended for household use only. Before First Use 1. Remove all stickers, packing material, and literature. 2. Wash all parts as instructed in the Care and Cleaning section. 3. Pour cold water up to 11-cup level mark in the water reservoir. Brew it through as instructed in BREWING, but do not add coffee grounds to the paper filter. When done, turn off the coffeemaker and discard the water from the carafe. BREWING 1. Lift the one-piece cover. Use water markings on carafe to... * Filters not included* No incluye los filtros * Model/Modelo ❍ CM9050 For online customer service and to register your product, go to www.prodprotect.com/applica Also view the details for our latest sweepstakes! IMPORTANT WASH CARAFe BeFoRe FIRST USe! IMPORTANTE ¡lAVe lA JARRA ANTeS del PRIMeR USo! 2-CUP PROgRAMMAblE Coffeemaker Cafetera PROgRAMAblE DE 2 T AZAS CustomerCare line: USA/Canada 1-800-231-9786 Mexico 01-714-2500 Accessories/Parts (USA / Canada) Accesorios/Partes... IMPORTANT WASH CARAFE BEFORE FIRST USE! IMPORTANT LA\fER LA CARAFE A\fANT LA PREMIÈRE UTILISATION! 12\bCUP PROGRAMMABLE \LCOFFEEMAKER CAFETIÈRE PROGRAMMABLE DE 12 T\LASSES MOdEl/MOdÈlE ❍ CM9050C Service Line à la clientèle : Ca\fada 1-\b00-231-97\b6 Accessoires/Pièces (Ca\fada) 1-\b00-73\b-0245 Pour accéder au service à la clientèle en ligne ou pour inscrire votre produit e\f lig\fe, re\fdez-vour à www.prodprotect.com/applica Customer Care Line: USA 1-\b00-231-97\b6 Accessories/Parts (USA)... * * Filters not included* No incluye los filtros Model/Modelo ❍ CM1010B For online customer service and to register your product, go to www.prodprotect.com/applica 2 CuP PROGRAMMABLE COFFEEMAKER CAFETERA PROGRAMABLE DE 2 TAZAS CustomerCare Line: USA/Canada 1-800-231-9786 Mexico 01-714-2503 Accessories/Parts (USA / Canada) Accesorios/Partes (ee.UU / Canadá) 1-800-738-0245 IMPORTANT WASH CARAFE BEFORE FIRST uSE! IMPORTANTE ¡LAVE LA JARRA ANTES DEL PRIMER uSO! MODELO/MODEL ❍ BCM1411B CAFETERA PROGRAMABLE DE 12 \UTAZAS 12-CUP PROGRAMMABLE\U COFFEEMAKER \fMPORTANTE ¡LAVE LA \bARRA ANTES DEL PR\fMER USO! \fMPORTANT WASH CARAFE BEFORE F\fRST USE! Customer Care Line: USA 1-\f00-231-\b7\f6 Accessories/Parts (USA) 1-\f00-73\f-0245 Servicio para el cliente: México 01-\f00 714-2503 Accesorios/Partes (EE.UU) 1-\f00-73\f-0245 \037\036 \t\037\b\031\007 \037\036\035\034\033 \021\023 \016 ❍ \b\035\022\013\033 ❍ \006\f\033 ❍ \003 \021\035\023 \022\024 ❍ \201\026 \032\031\035\013\033 ❍ \005\034\021\026\032\027\033 \025\026 \021\022\023\024\031\020\033 ❍ \006\f\033 \021\026\032\027\020\033 \013\022\001\022\027\035\013\033 \022\024\033 ❍ \003\036\035\033 \017\r\033 \035\026 ❍ \006\f\033 ❍ \006\f\033 \024 ❍ \006\f\033 \f\023\033 ❍ \003 \023 ❍ \006\f\033 ❍ \203\035\035\021\033 ❍ \220\025 \017\023 ❍ \003\036\035\033... Please Read and Save this Use and Care Book Por favor lea este instructivo antes de usar el producto Veuillez lire et conserver ce guide d'entretien et d'utilisation Model Modelo Modèle ❑ DCM2900W USA/Canada 1-800-231-9786 Mexico 01-800-714-2503 www.applicaconsumerproductsinc.com Accessories/Parts (USA/Canada) Accesorios/Partes (EE.UU/Canadá) Accessoires/Pièces (É.-U./Canada) 1-800-738-0245 Register your product online at www.prodprotect.com/applica, for a chance to WIN $100,000! Registre su... Por favor lea este instructivo antes de usar el producto Please Read and Save this Use and Care BookCafetera de 12 tazas 12-Cup Coffeemaker IMPORTANTE / IMPORTANT LAVE LA JARRA ANTES DEL PRIMER USO WASH CARAFE BEFORE FIRST USE! Modelo Model❑ DE711 USA/Canada 1-800-231-9786 Mexico 01-800-714-2503www.blackanddecker.com Accesorios/Partes (EE.UU/Canadá) Accessories/Parts (USA/Canada) 1-800-738-0245 DE711Pub1000003264 9/7/06 8:49 AM Page 1 2-Cup Coffeemaker Cafetera de 2 tazas Cafetière de 2 tasses IMPORTANT / IMPORTANTE / IMPORTANT WASH CARAFE BEFORE FIRST USE! ¡LAVE LA JARRA ANTES DEL PRIMER USO! LAVER LA CARAFE AVANT LA PREMIÈRE UTILISATION! Register your product online at www.prodprotect.com/applica, for a chance to WIN $ 00,000! For US residents only Accessories/Parts (USA/Canada) -800-738-0245 USA/Canada -800-23 -9786 Mexico 0-800-7 4-2503 ... 2-Cup Coffeemaker Cafetera de 2 tazas Cafetière de 2 tasses IMPORTANT / IMPORTANTE / IMPORTANT WASH CARAFE BEFORE FIRST USE! ¡LAVE LA JARRA ANTES DEL PRIMER USO! LAVER LA CARAFE AVANT LA PREMIÈRE UTILISATION! Register your product online at www.prodprotect.com/applica, for a chance to WIN $ 00,000! For US residents only Accessories/Parts (USA/Canada) -800-738-0245 USA/Canada -800-23 -9786 Mexico 0-800-7 4-2503 ... Please Read and Save this Use and Care Book Por favor lea este instructivo antes de usar el producto Veuillez lire et conserver ce guide d'entretien et d'utilisation IMPORTANT / IMPORTANTE / IMPORTANT WASH CARAFE BEFORE FIRST USE! LAVE LA JARRA ANTES DEL PRIMER USO LAVER LA CARAFE AVANT LA PREMIÈRE UTILISATION! 12-Cup Coffeemaker Cafetera de 12 Tazas Cafetière de 12 tasses Model Modelo Modèle❑ DLX900 USA/Canada 1-800-231-9786 Mexico 01-800-714-2503www.blackanddecker.com Accessories/Parts (USA/Canada)... MILL & BREW 12-CUP PROGRAMMABLE CO FFEE MAKER CAFETERA DE 12 TA\fAS PROGRAMABLE CAFETIÈRE PROGRAMMABLE DE 12 TASSES \037\036 \bse & care man\bal man\bal de \bso y c\bidado g\bide d'\btilisation et d'entretien CM5000BD CM5000GD CM5000RD CM5000WD getting started with your mill & brew \foffee maker PreP\brese a usar su su \fatetera de mill & \bbrew Pour \fommen\fer a Ve\f la \fatetiËre mill & brew CM5000BD | CM5000GD | CM5000RD | CM5000WD MILL & BREW™ \b2-CUP PROGRAMMABLE COFFEE MAKER CAFEtièRE PROGRAMMABLE \fE \b2 t AssEs use & care manual guide d'utilisation et d'entretien CM5000BCK t Towson, Maryland-based Stanley Black & Decker sells 33 different coffee makers, so it's best to consult your owner's manual for specific questions about the operation of your model. In the manuals it supplies, the company reminds consumers that a good cup of coffee requires four elements: good water, fresh coffee beans, even saturation of the coffee in the water, and a proper proportion of water to coffee. The first two elements are up to you. The coffee maker takes care of the rest. Many Black & Decker coffee makers feature a delayed brewing function that turns on the coffee maker at a preset time. Even if you aren't using this feature, it's a good idea to set the clock to the correct time of day just in case. To set the clock, be sure to plug in the unit. The display will flash "12:00." Press the HR button to set the hour. The display cycles from 1 to 12, then "PM" appears in the top right of the display and it repeats the cycle. Release the button at the correct hour. Press the MIN button to select minutes and release it at the current time. To program the unit to start brewing at a particular time of day, press the PROG button and select the time you want brewing to begin, using the same buttons you used to set the time of day. Once you've set the time, the display will flash several times, then revert to the time of day. At this point, press the AUTO button to activate the program. To brew coffee, you first need to add water. Fill the reservoir with cold water to the line denoting the number of cups you want to brew. Do not fill the reservoir past the line indicating its maximum capacity or you'll have a big mess on your hands. Next, you'll need to use a filter. Put a filter into the filter basket in the top of the machine. Be sure to use the proper filter for your machine. You can consult your owner's manual if you aren't sure which one to use. Some Black & Decker models, specifically the ones that grind coffee, don't require a filter. Once the filter is in place, you'll want to add your coffee of choice. Spoon coffee into the filter. The company recommends 1 heaping tablespoon per 6-ounce cup, but you may want to go up to 2 tablespoons, depending on how strong you like it. Distribute the coffee evenly in the bottom of the filter to ensure proper saturation. Set the carafe in place with the pour-through lid on it and press the ON/OFF button to begin brewing. If your unit has the Sneak-A-Cup feature, you can remove the carafe at any time to fill your cup. This interrupts the brewing process for 20 seconds. If you need to turn off the machine completely, press the ON/OFF button again. If your coffee maker includes a grind function, add beans in the same proportion as ground coffee: 1 to 2 tablespoons per cup. Select the grind setting according to the number of cups you're brewing. After filling the reservoir with water, press the ON/OFF button once. The machine will grind the beans and brew the coffee immediately afterwards. Be sure to set this to OFF if you're brewing already ground coffee. You should clean the coffee maker after every use by throwing away the grounds and filter, as well as washing the filter basket and carafe by hand or in the dishwasher. You should treat the coffee maker with vinegar once a month to prevent scale buildup from hard water. Fill the reservoir approximately half full with white vinegar, then fill it the rest of the way with water. Put a clean filter in the filter basket. Push the ON/OFF button to start the brewing cycle. Let the carafe fill about halfway, then turn off the coffee maker by pushing the ON/OFF button once again. Let the coffee maker and carafe soak for 15 minutes, then turn on the machine to complete the cycle. Discard the vinegar solution and filter, then fill the reservoir with fresh water and run the machine through a brewing cycle to flush out the vinegar. Repeat brewing cycle if the vinegar smell isn't completely gone. c) If an extension cord is used: 1) The marked electrical rating of the extension cord should be at least as great as the electrical rating of the appliance; 2) If the appliance is of the grounded type, the extension cord should be a grounding-type 3-wire cord; and 3) The cord should be arranged so that it will not drape over the counter top or tabletop where it can be pulled on by children or tripped over.Note: If the power cord is damaged, please contact the warranty department listed in these instructions. This product is for household use only.GETTING STARTED• Remove all packing material, any stickers, and the plastic band around the power plug.• Wash removable parts as instructed in CARE AND CLEANING.• Open cover and insert basket type paper filter into removable filter basket.• Pour fresh cold water up to 12-cup (MAX) mark into water reservoir.• Brew water through appliance following BREWING COFFEE instructions without coffee grounds.• Discard water from carafe and paper filter.• Turn off coffeemaker, unplug and allow to cool down.BREWING COFFEE1. Lift cover. Use water markings on carafe to fill water reservoir with water to your desired level.2. Place a basket type paper filter into the filter basket. Add ground coffee, (we recommend a heaping tablespoon for every cup). Close the cover.3. Place carafe on the "Keep Hot" carafe plate and plug in the unit.4. Toggle the on/off (I/O) switch to turn on (I) the coffeemaker.5. Replace the carafe on the "Keep Hot" carafe plate when not serving to keep coffee hot.6. Toggle the on/off (I/O) switch to turn off (O) the coffeemaker.SNEAK-A-CUP® FEATURERemove the carafe and brewing is paused. The carafe must be placed back on the "Keep Hot" carafe plate in 30 seconds to prevent overflow. Brewing begins again.This product contains no user serviceable parts. Refer service to qualified service personnel.Make sure your coffeemaker is unplugged and cool.1. Remove filter basket. Discard used paper filter and coffee grounds.2. Wash filter basket, carafe and carafe lid in dishwasher (top rack) or by hand in hot water with dish soap.3. Wipe outside of coffeemaker and carafe plate with a soft, damp cloth.Note: Do not use abrasive cleansers or scouring pads. Never immerse the coffeemaker in water.4. To clean the inside of the cover, open the cover and leave in the open position; wipe with a damp cloth.CLEANING WITH VINEGARNote: With regular use, minerals and hard water can clog your coffeemaker. A full cleaning with vinegar is recommended once a month.1. Pour white vinegar into water reservoir up to the 6-cup mark on the water window. Add cold water up to the 12-cup mark.2. Put a paper filter in filter basket and close cover. Set empty carafe on the carafe plate.3. Turn coffeemaker on. Let half the cleaning mixture brew into carafe (until level is around 5). Turn off coffeemaker and let it soak for at least 15 minutes.4. Turn coffeemaker on again and brew remaining cleaning mixture into carafe. Turn coffeemaker off; empty carafe and discard paper filter.5. Fill reservoir with cold water to 12-cup line; replace carafe on carafe plate and then turn coffeemaker on for a complete brewing cycle to flush out remaining cleaning mixture. You may want to repeat this step to completely remove the vinegar smell/taste.6. Wash filter basket and carafe as instructed in CARE AND CLEANING.Please Read and Save this Use and Care Book. POLARIZED PLUG (120V Models Only)This appliance has a polarized plug (one blade is wider than the other). To reduce the risk of electric shock, this plug is intended to fit into a polarized outlet only one way. If the plug does not fit fully into the outlet, reverse the plug. If it still does not fit, contact a qualified electrician. Do not attempt to modify the plug in any way.TAMPER-RESISTANT SCREWWarning: This appliance is equipped with a tamper-resistant screw to prevent removal of the outer cover. To reduce the risk of fire or electric shock, do not attempt to remove the outer cover. There are no user-serviceable parts inside. Repair should be done only by authorized service personnel. ELECTRICAL CORDa) A short power-supply cord is provided to reduce the risks resulting from becoming entangled in or tripping over a longer cord.b) Extension cords are available and may be used if care is exercised in their use.Product may vary slightly from what is illustrated. USA/Canada 1-800-465-6070Accessories/Parts 1-800-738-0245Register your product at www.prodprotect.com/blackanddeckerWARNINGRISK OF FIRE OR ELECTRIC SHOCK. DO NOT OPEN.The lightning symbol refers to "dangerous voltage"; the exclamation symbol refers to maintenance instructions. See below.Warning: To reduce the risk of fire or electric shock, do not remove the cover of the coffeemaker. There are no user-serviceable parts inside. Repair should be done by authorized service personnel only.IMPORTANTWASH CARAFE BEFORE FIRST USE! 1. Cover 2. Vortex™ Showerhead† 3. Removable filter basket (Part # CM0915-01) 4. Easy-to-view water window 5. Sneak-A-Cup® interrupt feature† 6. Hinged carafe lid (Part # CM0915-02)† 7. Carafe (Part # CM0915-03) 8. Nonstick "keep hot" carafe plate 9. I/O switch 10. Cord storage (inside of unit)Note: † indicates consumer replaceable/removable parts28439 E/FT22-9002286-AMade in China. Fabriqué en Chine.BLACK+DECKER and the BLACK+DECKER logos are trademarks of The Black & Decker Corporation, used under license by Spectrum Brands, Inc. for its manufacturing and sale of this product. All rights reserved. BLACK+DECKER et les logos BLACK+DECKER sont des marques de commerce de Black & Decker Corporation, utilisées sous licence par Spectrum Brands, Inc. pour la fabrication et la vente de ce produit. Tous droits réservés.All other marks are Trademarks of Spectrum Brands, Inc.Toutes les autres marques sont des marques de commerce de Spectrum Brands, Inc.© 2021 Spectrum Brands, Inc., Middleton, WI 53562. All rights reserved.For service, repair or any questions regarding your appliance, please call our Customer Service Line at 1-800-465-6070. Please DO NOT return the product to the place of purchase. Also, please DO NOT mail product back to manufacturer, nor bring it to a service center. You may also want to consult the website listed on the cover of this pamphlet.Warranty Information (Applies only in the United States and Canada)What does it cover?• Any defect in material or workmanship provided; however, Spectrum Brands' liability will not exceed the purchase price of product.For how long?• Two years from the date of original purchase with proof of such purchase.What will we do to help you?• Provide you with a reasonably similar replacement product that is either new or factory refurbished.How do you get service?• Save your receipt as proof of date of sale.• Visit the online service website at www.prodprotect.com/blackanddecker, or call toll-free 1-800-465-6070, for general warranty service.• If you need parts or accessories, please call 1-800-738-0245.How does state law relate to this warranty?• This warranty gives you specific legal rights. You may also have other rights that vary from state to state or province to province.What does your warranty not cover?• Damage from commercial use• Damage from misuse, abuse or neglect• Products that have been modified in any way• Products used or serviced outside the country of purchase• Glass parts and other accessory items that are packed with the unit• Shipping and handling costs associated with the replacement of the unit• Consequential or incidental damages (Please note, however, that some states do not allow the exclusion or limitation of consequential or incidental damages, so this limitation may not apply to you.)Are there additional warranty exclusions?This warranty shall not be valid where it is contrary to U.S. and other applicable laws, or where the warranty would be prohibited under any economic sanctions, export control laws, embargos, or other restrictive trade measures enforced by the United States or other applicable jurisdictions. This includes, without limitation, any warranty claims implicating parties from, or otherwise located in, Cuba, Iran, North Korea, Syria and the disputed Crimea region. At the end of this product's life, you can mail it to Spectrum Brands at 507 Stokely Drive, Deforest, WI 53532 marked "Product Takeback: Please Recycle!"Page 2Veuillez lire et conserver ce guide d'entretien et d'utilisation.• Lire toutes les directives.• Ne pas toucher aux surfaces chaudes; utiliser les poignées et les boutons.• Afin d'éviter les risques d'incendie, de choc électrique ou de blessures, ne pas immerger le cordon, la fiche ou la base de l'appareil dans l'eau ou tout autre liquide.• Exercer une étroite surveillance lorsque l'appareil est utilisé par un enfant ou près d'un enfant.• Débrancher l'appareil lorsqu'il n'est pas utilisé et le nettoyage. Laisser refroidir l'appareil avant d'installer ou de retirer des pièces, et avant de le nettoyer.• Ne pas utiliser un appareil dont la fiche ou le cordon est abîmé, qui présente un problème de fonctionnement, qui est tombé par terre ou qui est endommagé de quelque façon que ce soit. Communiquer avec le Service de soutien à la clientèle au numéro sans frais indiqué à la section « Garantie ». • L'utilisation d'accessoires non recommandés par le fabricant de l'appareil présente des risques d'incendie, de choc électrique ou de blessures.• Ne pas utiliser l'appareil à l'extérieur.• Ne pas laisser pendre le cordon sur le bord d'une table ou d'un comptoir ni le laisser entrer en contact avec une surface chaude.• Ne pas placer l'appareil sur le dessus ou près d'un élément chauffant électrique ou à gaz ni dans un four chaud.• Pour débrancher, éteindre toute commande hors tension, puis retirez la fiche de la prise murale.• Ne pas utiliser cet appareil pour d'autres fins que celles prévues.• Garder le couvercle sur la carafe lorsque l'appareil est utilisé.• Des brûlures peuvent de produire si le couvercle de la carafe est retiré pendant les cycles d'infusion.• La carafe est conçue pour être utilisée avec cet appareil. Il ne doit jamais être utilisé sur une cuisinière.• Ne pas déposer la carafe chaude sur une surface mouillée ou froide.• Ne pas utiliser une carafe craquelée ou une carafe avec une poignée est lâche ou affaiblie.• Ne pas nettoyer la carafe avec des produits nettoyants, des tampons en laine d'acier ou d'autres matériaux abrasifs.• Cet appareil n'est pas conçu pour être utilisé par des personnes (notamment des enfants) dont les capacités physiques, sensorielles ou mentales sont réduites ou qui manquent d'expérience ou de connaissances, à moins qu'elles ne soient supervisées ou dirigées par une personne responsable de leur sécurité pendant l'utilisation.• Exercer une étroite surveillance lorsque l'appareil est utilisé par un enfant ou près d'un enfant.• L'appareil n'est pas conçu pour être utilisé avec une minuterie externe ou un dispositif de télécommande séparé. Cet appareil est conçu pour un usage domestique seulement.FICHE POLARISÉE (Modèles de 120 V seulement)L'appareil est muni d'une fiche polarisée (une lame plus large que l'autre). Afin de minimiser les risques de secousses électriques, ce genre de fiche n'entre que d'une façon dans une prise polarisée. Lorsqu'on ne peut insérer la fiche à fond dans la prise, il faut tenter de le faire après avoir inversé les lames de côté. Si la fiche n'entre toujours pas dans la prise, il faut communiquer avec un électricien certifié. Il ne faut pas tenter de modifier la fiche.VIS INDESSERRABLEAvertissement : L'appareil est doté d'une vis indesserrable empêchant l'enlèvement du couvercle extérieur. Pour réduire les risques d'incendie ou de secousses électriques, ne pas tenter de retirer le couvercle extérieur. L'utilisateur ne peut pas remplacer les pièces de l'appareil. En confier la réparation seulement au personnel des centres de service autorisés.CORDON D'ALIMENTATIONa) Un cordon d'alimentation court est fourni pour éviter qu'un cordon long s'emmêle ou fasse trébucher.b) Des rallonges électriques sont disponibles et peuvent être utilisées avec prudence.c) En cas d'utilisation d'une rallonge : 1) Le calibre indiqué de la rallonge doit être au moins aussi élevé que celui de l'appareil, 2) si l'appareil est mis à la terre, la rallonge doit être de type mise à la terre avec 3 broches; et 3) le cordon électrique doit être disposé de façon à ce qu'il ne pende pas du comptoir ou de la table, qu'il ne soit pas à la portée des enfants et qu'il ne fasse pas trébucher.Remarque : Si le cordon d'alimentation est endommagé, veuillez communiquer avec le Service de la garantie dont les coordonnées figurent dans les présentes instructions.Cet appareil est conçu pour un usage domestique seulement.POUR COMMENCER• Retirer tout matériau d'emballage, toute étiquette et la bande de plastique entourant la fiche.• Lavar toutes les pièces amovibles comme indiqué à la section ENTRETIEN ET NETTOYAGE • Ouvrir le couvercle et insérer un filtre en papier de type panier dans le porte-filtre amovible.• Ouvrir le couvercle et verser de l'eau froide dans le réservoir jusqu'à la marque indiquant 12 tasses.• Infuser de l'eau dans la cafetière sans ajouter de café moulu,• Jeter l'eau de la carafe et le filtre en papier du panier-filtre.• Arrêter la cafetière, puis la débrancher pour lui permettre de refroidir.INFUSION DU CAFÉ1. Soulever le couvercle. Utiliser les marques de mesure sur la verseuse pour remplir le réservoir d'eau au niveau voulu.2. Placer un filtre en papier de type panier dans le porte-filtre. Ajouter du café moulu (nous recommandons une cuillère à soupe comble par tasse). Fermer le couvercle.3. Placer la verseuse sur la plaque chauffante et brancher la cafetière.4. Appuyer sur l'interrupteur marche/arrêt (I) pour mettre la cafetière en marche.5. Après avoir versé du café, replacer la verseuse sur la plaque chauffante pour garder le café au chaud.6. Appuyer sur l'interrupteur marche/arrêt (O) pour éteindre la cafetière. FONCTION SNEAK-A-CUP®Enlever la carafe; l'infusion s'interrompt alors. La carafe doit être replacée sur le réchaud dans les 30 secondes suivantes pour éviter les débordements. L'infusion reprend.L'utilisateur ne peut entretenir aucune composante du produit. En confier l'entretien à du personnel qualifié.Veiller à ce que la cafetière soit débranchée et refroidie.1. Enlever le panier-filtre. Jeter le filtre en papier usagé et le marc de café.2. Laver le panier-filtre et la carafe dans le lave-vaisselle (panier supérieur) ou à la main dans de l'eau chaude savonneuse3. Essuyer la partie externe de l'appareil et le réchaud à l'aide d'un linge doux humide.Remarque : Ne pas utiliser de nettoyants abrasifs ou de tampons à récurer. Ne jamais immerger la cafetière.4. Pour nettoyer l'intérieur du couvercle, ouvrir le couvercle et le laisser en position ouverte. essuyer à l'aide d'un linge humide.NETTOYAGE AVEC DU VINAIGRERemarque : Des minéraux provenant d'une eau dure peuvent bloquer la cafetière. Un nettoyage est recommandé tous les mois.1. Verser du vinaigre blanc dans le réservoir d'eau jusqu'à la marque de 6 tasses de l'indicateur du niveau d'eau. Ajouter de l'eau jusqu'à la marque de 12 tasses.2. Insérer un filtre en papier dans le panier-filtre et fermer le couvercle monopièce. Mettre la carafe vide sur le réchaud.3. Mettre en marche la cafetière et laisser infuser la moitié de la solution au vinaigre dans la carafe (jusqu'à ce que le niveau d'eau atteigne environ la marque de 5 tasses de l'indicateur du niveau d'eau). Arrêter la cafetière et y laisser la solution pendant au moins 15 minutes pour ramollir les dépôts.4. Mettre en marche la cafetière et laisser le reste de la solution de nettoyage s'écouler dans la carafe. Arrêter la cafetière, vider la carafe et jeter le filtre.5. Remplir le réservoir d'eau jusqu'à la marque de 12 tasses, replacer la carafe vide sur le réchaud et mettre en marche la cafetière le temps d'un cycle d'infusion complet afin d'éliminer le reste de la solution nettoyante. Il faudra peut-être répéter cette étape pour éliminer l'odeur/le goût du vinaigre.6. Laver le panier-filtre et la carafe en suivant les recommandations relatives au nettoyage normal.Le produit peut différer légèrement de celui qui est illustré.Canada 1-800-465-6070Accessoires/Pièces 1-800-738-0245Inscrire votre à l'adresse www.prodprotect.com/blackanddecker 1. Couvercle 2. Douchette Vortex™† 3. Porte-filtre amovible (pièce nº CM0915-01) 4. Fenêtre de repère du niveau d'eau 5. Fonction d'arrêt temporaire d'infusion Sneak-A-Cup®† 6. Couvercle articulé de la verseuse (pièce nºCM0915-02)† 7. Verseuse (pièce nºCM0915-03) 8. Plaque chauffante antiadhésive 9. Interrupteur marche/arrêt 10. Rangement pour le cordon (à l'intérieur de la cafetière)Note: Le symbole † désigne les pièces remplaçables par l'utilisateur ou moviblesIMPORTANTE : LAVER LA CARAFE AVANT LA PREMIÈRE UTILISATION!Modèle : CM0915BKD, CM0915BKD-FDAVERTISSEMENTAFIN D'ÉVITER LES RISQUES D'INCENDIE OU DE SECOUSSES ÉLECTRIQUES.NE PAS OUVRIR.L' éclair représente une tension dangereuse.Le point d'exclamation indique qu'il s'agit d'importantes consignes d'entretien. Voir plus bas.AVERTISSEMENT : Afin d'éviter les risques d'incendie ou de secousses électriques, ne pas retirer le couvercle de la cafetière. L' utilisateur ne peut réparer aucune des pièces internes. En confier les réparations uniquement au personnel d'un centre de service utorisé.BESOIN D'AIDE?Pour communiquer avec les services d'entretien ou de réparation, ou pour adresser toute question relative au produit, composer le numéro sans frais approprié indiqué sur la page couverture. NE PAS retourner le produit où il a été acheté. NE PAS poster le produit au fabricant ni le porter dans un centre de service. On peut également consulter le site web indiqué sur la page couverture.Garantie limitée de deux ans (Valable seulement aux Ëtats-Unis et au Canada)Quelle est la couverture?• Tout défaut de main-d'oeuvre ou de matériau; toutefois, la responsabilité de la société. Spectrum Brands, Inc. se limite au prix d'achat du produit.Quelle est la durée?• Deux années à compter de la date d'achat initiale, avec une preuve d'achat.Quelle aide offrons nous?• Remplacement par un produit raisonnablement semblable nouveau ou réusiné.Comment se prévaut-on du service?• Conserver son reçu de caisse comme preuve de la date d'achat.Visiter notre site web au www.prodprotect.com/blackanddecker, ou composer sans frais le 1-800 465-6070, pour obtenir des renseignements généraux relatifs à la garantie.• On peut également communiquer avec le service des pièces et des accessoires au 1-800 738-0245.Quelles lois régissent la garantie?• Les modalités de la présente garantie donnent des droits légaux spécifiques. L'utilisateur peut également se prévaloir d'autres droits selon l'état ou la province qu'il habite.Qu'est-ce que la garantie ne couvre pas?• Des dommages dus à une utilisation commerciale.• Des dommages causés par une mauvaise utilisation ou de la négligence.• Des produits qui ont été modifiés.• Des produits utilisés ou entretenus hors du pays où ils ont été achetés.• Des pièces en verre et tout autre accessoire emballés avec le produit.• Les frais de transport et de manutention reliés au remplacement du produit.• Des dommages indirects (il faut toutefois prendre note que certains états ne permettent pas l'exclusion ni la limitation des dommages indirects).Existe-t-il d'autres exclusions à la garantie?• La présente garantie n'est pas valable si elle contrevient aux lois en vigueur aux Ëtats-Unis ou autres lois applicables ailleurs, ou là où elle serait interdite en raison de sanctions économiques, de lois sur le contrôle des exportations, d'embargos ou d'autres mesures de restriction du commerce imposées par les Ëtats-Unis ou d'autres juridictions applicables. Ceci comprend, notamment, toutes réclamations au titre de la garantie impliquant des parties situées à Cuba, en Iran, en Corée du Nord, en Syrie et ailleurs dans la région contestée de la Crimée, ou provenant de ces endroits.À la fin de la durée utile de ce produit, vous pouvez le poster à Spectrum Brands au 507 Stokely Drive, Deforest, WI 53532 en indiquant sur la boîte « Product Takeback: Please Recycle! » USA/Canada 1-800-231-9786 Accessories/Parts 1-800-738-0245 Register your product at www.prodprotect.com/applica 12-CUP PROGRAMMABLE COFFEEMAKER 1. Cover 2. Showerhead † 3. Removable filter basket (Part # CM2020B-01) 4. Easy-to-view water window 5. Digital display 6. Control panel 7. Sneak-A-Cup® interrupt feature † 8. Duralife™ glass carafe Part # Part # Black (CM2020B-02), Red (CM2020R-02) 9. Nonstick "keep hot" carafe plate 10. Built-in cord storage (not shown) Note: † indicates consumer replaceable/removable parts MODEL ❍ CM2020B ❍ CM2020R Please Read and Save this Use and Care Book. IMPORTANT SAFEGUARDS When using electrical appliances, basic safety precautions should always be followed to reduce the risk of fire, electric shock, and/or injury to person's including the following: ❍ Read all instructions. ❍ Do not touch hot surfaces. Use handles or knobs. ❍ To protect against fire, electric shock and injury to persons do not immerse cord, plugs or appliance in water or other liquid. ❍ Close supervision is necessary when any appliance is used by or near children. ❍ Unplug from outlet when not in use and before cleaning. Allow to cool before putting on or taking off parts, and before cleaning the appliance. ❍ Do not operate any appliance with a damaged cord or plug, or after the appliance malfunctions or has been damaged in any manner. Return appliance to the nearest authorized service facility for examination, repair or adjustment. ❍ The use of accessory attachments not recommended by the appliance manufacturer may result in fire, electric shock or injury to persons. ❍ Do not use outdoors. ❍ Do not let cord hang over edge of table or counter, or touch hot surfaces. ❍ Do not place on or near a hot gas or electric burner, or in a heated oven. ❍ To disconnect, turn timer control to OFF, then remove plug from wall outlet. Product may vary slightly from what is illustrated. IMPORTANT WASH CARAFE BEFORE FIRST USE! ❍ Do not use this appliance for other than intended use. ❍ Keep lid on the carafe when in use. ❍ Scalding may occur if the lid is removed during the brewing cycles. ❍ The carafe is designed for use with this appliance. It must never be used on a range top. ❍ Do not set a hot carafe on a wet or cold surface. ❍ Do not use a cracked carafe or a carafe having a loose or weakened handle. ❍ Do not clean carafe with cleansers, steel wool pads or other abrasive material. SAVE THESE INSTRUCTIONS. This product is for household use only. POLARIZED PLUG (120V Models Only) This appliance has a polarized plug (one blade is wider than the other). To reduce the risk of electric shock, this plug is intended to fit into a polarized outlet only one way. If the plug does not fit fully into the outlet, reverse the plug. If it still does not fit, contact a qualified electrician. Do not attempt to modify the plug in any way. TAMPER-RESISTANT SCREW Warning: This appliance is equipped with a tamper-resistant screw to prevent removal of the outer cover. To reduce the risk of fire or electric shock, do not attempt to remove the outer cover. There are no user-serviceable parts inside. Repair should be done only by authorized service personnel. ELECTRICAL CORD a) A short power-supply cord is to be provided to reduce the risk resulting from becoming entangled in or tripping over a longer cord. b) Longer extension cords are available and may be used if care is exercised in their use. c) If an extension cord is used, 1) The marked electrical rating of the detachable power-supply cord or extension cord should be at least as great as the electrical rating of the appliance, 2) If the appliance is of the grounded type, the extension cord should be a grounding-type 3-wire cord, and 3) The longer cord should be arranged so that it will not drape over the countertop or tabletop where it can be pulled on by children or tripped over unintentionally. Note: If the power supply cord is damaged, it should be replaced by qualified personnel or in Latin America by an authorized service . How to Use This product is for household use only. GETTING STARTED • Wash removable parts as instructed in CARE AND CLEANING. • Pour fresh cold water up to 12-cup level mark into the water reservoir. • Place basket-style paper filter into removable filter basket. Place basket into filter basket holder. • Plug cord into standard electrical outlet. • Brew water through appliance without adding coffee grounds. This removes any dust or residue that may remain in the system during the manufacturing process. • Discard water from the carafe and paper filter from filter basket. • Turn off appliance; unplug and allow to cool down. SETTING THE CLOCK 1. Plug appliance into standard electrical outlet. 2. The digital clock display flashes12:00. 3. To change the time: Press HOUR button until the correct time appears on the display. When the time passes noon "PM" illuminates to let you know you are in PM time. If the "PM" is not illuminated it is AM time. 4. Press the MIN button to select the minutes. Note: If the appliance is unplugged or power is interrupted even momentarily, the time may need to be reset. BREWING COFFEE 1. Open cover. 2. Fill water reservoir using the carafe with desired amount of cold tap water. Do not exceed the 12-cup (MAX) level on the water reservoir. 3. Insert removable filter basket into filter basket holder. 4. Place an 8-12 cup basket-style paper filter into the removable filter basket. 5. Add desired amount of ground coffee. Close cover. 6. Make sure carafe lid is properly attached to the empty carafe. Close the lid. Note: Coffee may overflow if carafe lid is not properly placed. 7. Place empty carafe on the carafe plate. 8. Plug power cord into an outlet. 9. If regular brew strength is desired, your coffeemaker is set to brew coffee. 10. If strong coffee is desired, press the brew strength button to select the strong brew. The word STRONG is displayed. 11. Press ON/OFF button and brewing begins. 12. When coffee stops flowing into carafe, the brew cycle is complete. Coffeemaker beeps when brew cycle is finished. The time since brewing will be visible at the bottom of the digital display. 13. Once coffee grounds have cooled, carefully open cover and, discard used grounds. Close cover. 14. The coffeemaker will keep brewed coffee hot for 2 hours and then automatically turn off. 15. To turn off the coffeemaker at any time press the ON/OFF button. The ON/ OFF light goes off. Unplug appliance when not in use. BREWING 1 TO 4 CUPS Note: This feature slows down the brewing to extract the best flavor when brewing a small amount of coffee. 1. Add the appropriate amount of water for the number of cups to be brew